


For correct operation, the device should be connected to a power outlet with the earthing pin. The device should be used indoors, where the electric installation utilises unambiguously identified wires: phase and neutral. The pin grid array of the power socket should look like figure 1:



PE – safety contact | N – neutral contact | L-phase contact
Fig. 1 The pin grid array of the power socket (PN-E-93201:1997)

To connect the EVER surge protector:

- connect the outlet plug of the surge protector to the power outlet,
- plug in the outlet plugs of the protected devices to the power outlets on the surge protector
- switch on the mains switch,

Signalization of the strip's functional states:

- the presence of voltage in the mains sockets and anti-surge protection are signalled with a highlighted text "PROTECTED",
- if the text "PROTECTED" is not highlighted, it means that there no external supply is present or that one of the protections has been triggered.

OPERATION GUIDELINES

- If there is no power in the strip's sockets (the switch is not highlighted), make sure the strip's cord is connected correctly and there is power in the mains socket to which the strip is connected. If there is still no power in the strip's sockets, despite its presence on the strip's plug, the product must be repaired. The information concerning repairs is available at www.ever.eu.
- The strip may only be used with installations with a protective (grounding) pin
- Due to the type and location of the fuse, the building installation's protection systems serve as one of the protection stages.
- Depending on the surface to which the strip is to be attached (concrete, brick, drywall), a relevant set of wall plugs and bolts must be used. The strip must be installed using the mounting template available at www.ever.eu.



NOTE! The surge protector is fully disconnected from the power network by unplugging the power lead plug from the socket, which should be easily accessible and located close to the device.

Product is designed for indoor use. Protect the device from humidity.

PARAMETERS \ NAME	ELITE USB
Part number	T/LZ11-ELI015/0000
Typ	01
Type	Surge protector
Rated voltage and frequency	~ 230 V / 50 Hz
Maximum current (total)	10 A
Single outlet maximum load	10 A
Maximum power (total)	2300 W
Number and type of power outlets	5; in accordance with NF C 61-314; System Child Protection
Circuit breaker	1 x 10 A fuse integrated with the power switch
Type of surge protection	SPD type 3
Protected lines	L - N
Energy absorption (total)	306 J
Test voltage $U_{OC(L-N)}$	6 kV
Voltage protection level $U_{P(L-N)}$	1,1 kV
Continous operating voltage U_c	~ 250 V
USB Charger	2x Port 5 V / 2,1 A (max)
Indicators	1x LED (power on, surge protector)
Plug	NF C 61-314
Power switch	2 –pole
Dimensions [W x D x H]	64 x 370 x 39 mm
Power cord length	1,5 m
Net weight	548 g
Warranty	12 years
Insurance	2500 EUR

Note: The manufacturer reserves the right to change the mentioned above parameters without notice.

ELITE USB



Appropriate utilisation of used up electric and electronic equipment helps to avoid consequences resulting from the presence of dangerous materials, as well as inappropriate disposal and processing of such equipment, which may be hazardous to human life and the environment. (Act dated 29 July 2005 on used up electric and electronic equipment, article 22.1 items 1 and 2).

According to the regulations binding in the European Union, a crossed rubbish bin symbol means that when a product is no longer used it should be disposed of at a special waste pickup site. This concerns the device itself, as well as other accessories marked with this symbol. Do not dispose of those products together with unsorted household waste.